

Ferno Mondial Funeral Transporter



PRODUCT INFO

Product Nr:	F0M6F-M3369
Length:	203 cm
Width:	59 cm
Height:	35-103cm
Weight:	36 kg
Max Load:	270 kg



Ferno Mondial Funeral Transporter with SMART-LOAD™ Technology

The **Ferno Mondial Funeral Transporter** is designed for use with our mortuary stretchers and is perfectly suited for the dignified transport of coffins and deceased individuals. Thanks to its innovative **SMART-LOAD™ technology**, there's no need to manually operate a lever when loading or unloading the roll-in system into or out of a vehicle—the release mechanism is fully automatic. With the adapter included, our mortuary stretchers can be securely and easily attached. The adapter features two crossbars with stretcher supports and a fixed stop plate, ensuring a stable and reliable connection. Using the Ferno Mondial Funeral Transporter significantly reduces physical strain by transferring the weight of the deceased onto the trolley rather than the caregiver's back. You can wheel the trolley—along with the stretcher and the deceased—directly to the vehicle and effortlessly load the entire unit. The trolley is designed for a loading height of approximately 70 cm.

Enhanced Maneuverability and Comfort: A standout feature of the Ferno Mondial Funeral Transporter is the swivel function for all four wheels. By simply activating a lever at the foot end, the front castor wheels are unlocked—enabling full 360° maneuverability. When the front wheels are aligned straight again, they automatically lock back into place. This allows you to easily and precisely position the trolley close to beds or narrow spaces.

3 in 1 solution: Thanks to its high load capacity, the **Ferno Mondial Funeral Transporter** is not limited to use with stretchers. It is also suitable for coffin transport. With the included multifunctional adapter, both a stretcher and a coffin can be securely positioned and transported on the same stretcher, making a truly versatile solution for funeral homes and mortuary services.

- **Color-coded controls** with intuitive operation and automatic leg release
- **Large wheels** for smooth rolling on all surfaces
- **Front wheel locking system** for optimal steering control in confined spaces
- **Six adjustable height levels** for ergonomic handling and easier transfer of the deceased
- **Durable metal frame** for long-lasting, high-capacity use
- **Ergonomically shaped controls** at both the head and foot ends for comfortable handling
- **Two loading rollers** at the head end for easier vehicle access

Ferno Mondial Funeral Transporter is complete with adapter F0M161S and the M3369 stop plate.

Recommended option: F011U4 - Mortuary Stretcher M11U foldable with grey cover